

GL04P 動作確認済みPC一覧

2012年12月3日現在

- 一覧にない機種は動作確認が未実施のものであり、正常動作しないという意味ではありません。
- 動作確認はパソコンメーカー出荷状態のパソコンで行っております。周辺機器を増設したり、設定変更を行っている場合には新たな設定が必要か、正常動作しない場合があります。
- 動作確認済みの機種について正常動作を確認しておりますが、お客さまの環境において正常動作を保証するものではありません。また弊社で正常動作確認済みの機種でもパソコンの個体により正常動作しない可能性があります。

◆Acer

型番(機種名)	OS
Acer AO751h	Windows XP Home SP3 (32bit)
Acer Aspire 3810T	Windows Vista Home Basic SP2 (32bit)
Acer Aspire 5530	Windows Vista Business SP2 (64bit)
Acer Aspire 5750G	Windows 7 Home Basic SP1 (64bit)
Acer Aspire 7750G	Windows 7 Home Basic SP1 (64bit)
Acer Aspire one	Windows XP Professional SP3 (32bit)

◆Apple

型番(機種名)	OS
Macbook Pro(MB470J/A)	Mac OS 10.5.6 (32bit)
Macbook Air (MB543J/A)	Mac OS 10.6.8 (32bit)
Macbook Pro(MC721J/A)	Mac OS 10.7.1 (64bit)
Macbook Air (MC969J/A)	Mac OS 10.7.3 (32bit)
Macbook Air (MC505J/A)	Mac OS 10.6.5 (32bit)
Macbook Pro(MC371J/A)	Mac OS 10.6.3 (64bit)
Macbook (MC207J/A)	Mac OS 10.6.1 (32bit)
Macbook Pro(MB604J/A)	Mac OS 10.5.6 (32bit)
Macbook (MB466J/A)	Mac OS 10.5.5 (32bit)
Macbook (MB402J/A)	Mac OS 10.5.1 (32bit)
Macbook Pro(MA609J/A)	Mac OS 10.5 (32bit)
Macbook (MC371J/A)	Mac OS 10.6.4 (32bit)
iMac 21.5" (MC509J/A)	Mac OS 10.7 (32bit)
Macbook Air (MD223J/A)	Mac OS 10.8.2 (64bit)
Macbook Pro(MD103J/A)	Mac OS 10.8.2 (64bit)

◆ASUS

型番(機種名)	OS
ASUS 1015CX	Windows 7 Home Basic SP1 (32bit)
ASUS 1225B	Windows 7 Home Basic SP1 (32bit)
ASUS ASUS Eee PC 900-X	Windows XP Home SP2 (32bit)
ASUS EeePC1000H	Windows XP Professional SP3
ASUS N53S	Windows 7 Home Basic SP1 (32bit)
ASUS N73S	Windows 7 Home Basic (64bit)
ASUS UL 20A	Windows 7 Home Premium SP1 (64bit)
ASUS UX50V	Windows Vista Home Basic SP2 (32bit)

◆DELL

型番(機種名)	OS
Dell Alienware M11x	Windows 7 Home Premium (64bit)
Dell Alienware M17	Windows 7 Home Premium SP1 (64bit)
Dell Inspiron 1010	Windows XP Home SP3
Dell Inspiron 13z	Windows 7 Home Premium SP1 (64bit)
Dell Inspiron 1420	Windows Vista Home Basic SP2 (32bit)
Dell Inspiron 14R	Windows 7 Home Basic SP1 (64bit)
Dell Inspiron M4040	Windows 7 Ultimate (64bit)
Dell Inspiron N5110	Windows 7 Home Premium SP1 (64bit)
Dell Latitude D430	Windows XP Professional SP3
Dell Latitude D630	Windows XP Professional SP3
Dell Latitude E4200	Windows Vista Home Basic SP1 (32bit)
Dell Latitude E6420	Windows 7 Professional SP1 (64bit)
Dell Latitude E6500	Windows Vista Ultimate SP1 (64bit)
Dell Precision M2300	Windows Vista Business SP2 (32bit)
Dell Studio XPS13	Windows Vista Home Premium SP2 (32bit)
Dell Vostro 1200	Windows Vista Home Basic SP1 (32bit)
Dell Vostro 1400	Windows XP Professional SP3
Dell Vostro 3450	Windows 7 Home Basic SP1 (64bit)
Dell Vostro V131	Windows 7 Home Premium SP1 (64bit)
Dell XPS 15z	Windows 7 Home Premium SP1 (64bit)
Dell XPS M1330	Windows Vista Home Basic SP2 (32bit)
Dell XPS M1530	Windows Vista Home Premium SP2 (32bit)

◆Fujitsu

型番(機種名)	OS
FUJITSU AH520/2A FMVA552A	Windows 7 Home Premium (32bit)
Fujitsu FMV-BIBLO LOOX M/E10	Windows 7 Starter SP1 (32bit)
Fujitsu FMV-BIBLO LOOX R/A70	Windows Vista Business SP2 (32bit)
FUJITSU FMV-BIBLO LOOX T50U/V	Windows 7 Ultimate (32bit)
Fujitsu FMV-BIBLO MG/A75	Windows Vista Home Premium SP2 (32bit)
Fujitsu FMV-BIBLO MG/D70	Windows Vista Home Premium SP2 (32bit)
FUJITSU FMV-BIBLO MG50S	Windows XP Home SP3
Fujitsu FMV-BIBLO NB55UD	Windows Vista Home Premium SP1 (32bit)
Fujitsu FMV-BIBLO NF/G70	Windows 7 Home Premium SP1 (32bit)
FUJITSU FMV-BIBLO NF40U/V	Windows 7 Ultimate (32bit)
Fujitsu FMV-BIBLO NX70W/D	Windows Vista Home Premium SP2 (32bit)
FUJITSU FMV-BIBLO NX95T/D	Windows XP Home SP3
Fujitsu FMV-BIBLO R/E70	Windows 7 Professional SP1 (32bit)
Fujitsu FMV-DESKPOWER CE40U7	Windows 7 Ultimate (32bit)
FUJITSU FMVMTE50	Windows 7 Home Premium (32bit)
FUJITSU LOOX M Series FMVLME10V	Windows 7 Starter SP1 (32bit)

◆HP

型番(機種名)	OS
HP 2230s	Windows XP Professional SP3
HP Compaq 2210b	Windows XP Home Basic SP3
HP Compaq 6535s	Windows 7 Ultimate (64bit)
HP EliteBook 2730p	Windows Vista Home Basic SP2 (32bit)
HP EliteBook 8740w	Windows 7 Professional (32bit)
HP G60	Windows Vista Home Premium SP2 (32bit)
HP mini 110-1113TX	Windows XP Home SP3
HP Notebook PC dv7	Windows 7 Home Premium SP1 (32bit)
HP Pavilion dm3i	Windows 7 Home Basic SP1 (32bit)
HP Pavilion dv3000	Windows Vista Home Premium SP2 (32bit)
HP Pavilion dv5	Windows Vista Home Premium SP2 (32bit)
HP Pavilion dv9000	Windows Vista Home Premium SP2 (32bit)
HP Pavilion dv9200	Windows Vista Home Premium SP2 (32bit)
HP Pavilion dv9740	Windows Vista Home Premium SP2 (32bit)
HP Pavilion dv9852 eg	Windows Vista Home Premium SP2 (32bit)
HP Pavilion g6	Windows 7 Home Basic SP1 (64bit)
HP PC dv6a	Windows 7 Home Premium (32bit)
HP ProBook 4321s	Windows 7 Professional (64bit)
HP ProBook 4321s	Windows 7 Professional (64bit)
HP ProBook 4326s	Windows 7 Home Basic (32bit)
HP ProBook 4530s	Windows 7 Professional SP1 (64bit)

◆KOJINSHA

型番(機種名)	OS
kohjinsha SA1F00	Windows XP Home SP3

◆Lenovo

型番(機種名)	OS
IBM Thinkpad T42	Windows XP Professional SP3
IBM Thinkpad X31	Windows XP Professional SP3
IBM Thinkpad X41	Windows XP Professional SP3
Lenovo C200	Windows Vista Business SP2 (32bit)
Lenovo G550 (2958R7J)	Windows 7 Ultimate SP1 (64bit)
Lenovo IdeaPad G570	Windows 7 Home Basic SP1 (32bit)
Lenovo Ideapad S10	Windows XP Home SP3
Lenovo Ideapad S205	Windows 7 Home Basic SP1 (32bit)
Lenovo IdeaPad U350	Windows Vista Home Basic SP2 (32bit)
Lenovo ideapad Y510	Windows Vista Home Premium SP2 (32bit)
Lenovo ThinkPad E420	Windows 7 Home Basic SP1 (32bit)
Lenovo ThinkPad E520	Windows 7 Home Basic SP1 (32bit)
Lenovo Thinkpad R60e	Windows 7 Professional SP1 (32bit)
Lenovo Thinkpad SL400	Windows Vista Home Basic SP2 (32bit)
Lenovo Thinkpad T400	Windows XP Professional SP3
Lenovo Thinkpad T61	Windows XP Professional SP3
Lenovo ThinkPad X1 12912BJ	Windows 7 Professional (32bit)
Lenovo ThinkPad X100e 28762FJ	Windows 7 Professional SP1 (32bit)
Lenovo Thinkpad X200	Windows XP Professional SP3
Lenovo ThinkPad X201i	Windows 7 Professional SP1 (32bit)
Lenovo Thinkpad X300	Windows XP Professional SP3
Lenovo Thinkpad Z61t	Windows XP Professional SP3

◆MSI

型番(機種名)	OS
MSI MegaBook X340	Windows Vista Home Premium SP1 (32bit)
MSI U100	Windows XP Home SP3

◆NEC

型番(機種名)	OS
NEC LaVie L PC-LL570/GD	Windows XP Home SP3
NEC LAVIE L PC-LL850WG	Windows 7 Home Premium (32bit)
NEC Lavie LL550/M	Windows Vista Home Premium SP2 (32bit)
NEC Lavie LL870/W	Windows 7 Home Premium SP1 (32bit)
NEC Lavie LM330/V	Windows 7 Home Premium SP1 (32bit)
NEC LaVie PC-LC900SG	Windows 7 Ultimate (32bit)
NEC VALUESTAR N PC-VN550VG6B	Windows 7 Home Premium SP1 (32bit)
NEC Valustar VL550/ES wuth 23 inch Monitor	Windows 7 Home Premium SP1 (64bit)

◆Panasonic

型番(機種名)	OS
Panasonic CF-N8HYCADR	Windows 7 Professional SP1 (32bit)
Panasonic CF-N9KYDEDR	Windows 7 Professional (32bit)
Panasonic CF-R8GW1AJR	Windows Vista Business SP2 (32bit)
Panasonic CF-T5AW1PJR	Windows Vista Business SP2 (32bit)
Panasonic CF-Y7AWDBJR	Windows Vista Business SP1 (32bit)
Panasonic CF-Y7AWDPJR	Windows Vista Business SP2 (32bit)
Panasonic Let's note CF-T5MW4AJR	Windows Vista Business (32bit)

◆Sharp

型番(機種名)	OS
Sharp Mebius Note PC-WE40S	Windows 7 Ultimate (32bit)
Sharp Mebius PC-AE50M	Windows XP Home SP3
Sharp PC-FW50X	Windows Vista Home Premium (32bit)

◆SONY

型番(機種名)	OS
SONY VAIO VPCEE26FJ/BI	Windows 7 Home SP1 (32bit)
SONY VGN TT53FB	Windows 7 Home Premium SP1 (64bit)
SONY VGN-C51HB	Windows 7 Home Basic SP1 (32bit)
SONY VGN-C61HB	Windows Vista Home Basic SP2 (32bit)
SONY VGN-TZ73B	Windows 7 Ultimate SP1 (32bit)
SONY VPCEB18FJ/W	Windows 7 Home Premium SP1 (64bit)
SONY VPCEK23FJ/W	Windows 7 Home Premium SP1 (64bit)
SONY VPCYB19KJ/G	Windows 7 Home Premium (32bit)
SONY VPCZ219FJ/B	Windows 7 Home Basic SP1 (64bit)
SONY SVS15129CJB	Windows 8 Home Basic SP1 (64bit)

◆SOTEC

型番(機種名)	OS
SOTEC C103B4	Windows XP Home SP3
SOTEC WinBook DN5020	Windows 7 Ultimate (32bit)

◆TOSHIBA

型番(機種名)	OS
Toshiba dynabook AX/53C	Windows Vista Home Premium SP2 (32bit)
Toshiba dynabook CX/45C	Windows Vista Home Premium SP1 (32bit)
Toshiba dynabook MX/33LRD	Windows 7 Home Premium SP1 (32bit)
Toshiba dynabook SS RX1/S7A	Windows Vista Business SP1 (32bit)
Toshiba dynabook TV/64KWH PATV64KLTWH	Windows 7 Home Premium (32bit)
Toshiba dynabook TX/66E	Windows 7 Ultimate SP1 (32bit)
Toshiba Libretto W100	Windows 7 Home Premium (32bit)
Toshiba Libretto W100/11M	Windows 7 Home Premium (32bit)
Toshiba Qosmio F50	Windows Vista Home Premium SP2 (32bit)
Toshiba Qosmio FX/G7J PAFXG7JLR	Windows Vista Home Premium SP1 (64bit)
Toshiba Qosmio T851/D8CR	Windows 7 Home Premium SP1 (64bit)
Toshiba Satellite A660	Windows 7 Home Premium SP1 (64bit)
Toshiba Toshiba MX/33LWH	Windows 7 Ultimate (64bit)
Toshiba TX/67J2BLYD	Windows Vista Home Premium SP2 (32bit)